



CONSUMER SERVICES TECHNICAL
EDUCATION GROUP PRESENTS


L-66



Catalyst[™]
Cleaning Action

**ELECTRONIC
THREE-SPEED
AUTOMATIC
WASHERS
with
CATALYST
CLEANING ACTION[™]**

JOB AID
Part No. 4322673



INTRODUCTIION

This Job Aid, “*ELECTRONIC THREE-SPEED AUTOMATIC WASHERS with CATALYST CLEANING ACTION™*,” (Part No. 4322673), has been compiled to provide the most recent information on design, features, troubleshooting, service and repair procedures. For additional information on the basic washer components, refer to Job Aid #787930. For additional information on AccuWash, Automatic Temperature Control, refer to Job Aid #4322334.

GOALS AND OBJECTIVES

The goal of this Job Aid is to provide detailed information that will enable the service technician to properly diagnose malfunctions and repair of the clothes washer.

The objectives of the Job Aid are:

The service technician will -

- Understand proper safety precautions.
- Successfully troubleshoot and diagnose malfunction.
- Successfully perform necessary repairs.
- Successfully return the air conditioner to proper operational status.





WHIRLPOOL CORPORATION ASSUMES NO RESPONSIBILITY
FOR ANY REPAIRS MADE ON OUR PRODUCTS BY ANYONE
OTHER THAN AUTHORIZED SERVICE TECHNICIANS.

TABLE OF CONTENTS

SAFETY	III
SECTION ONE	
FEATURES	1
SECTION TWO	
THEORY OF OPERATION	7
SECTION THREE	
COMPONENT ACCESS	
COMPONENT LOCATION	15
ACCESSING CRITICAL COMPONENTS	16
SECTION FOUR	
COMPONENT TESTING & DIAGNOSIS	
SERVICE DIAGNOSTIC TESTS	25
ERROR CODES	27
TROUBLESHOOTING TEST PROCEDURES	29
SECTION FIVE	
TECH TIPS	
WIRING DIAGRAM	35
WARRANTY INFORMATION	35
MODEL/SERIAL NUMBER LOCATION	36
MODEL/SERIAL NUMBER DESIGNATION	36

SAFETY

 WARNING	
	ELECTRICAL SHOCK HAZARD Disconnect power before servicing the washer. Replace all panels before operating the washer. Failure to do so can result in death or electrical shock.

-- NOTES --

Section One


FEATURES

Catalyst Cleaning™

CATALYST CLEANING™ allows detergent to soak and penetrate the entire load giving improved stain and soil removal.

CATALYST CLEANING™ uses laundry detergent in a unique way. Water flushes the detergent from the dispenser to dissolve the detergent. Then the concentrated detergent mixture is sprayed on to the load while the washer spins at low speed.


CATALYST CLEANING™ will last one to five minutes, depending on the cycle selected. The washer then stops spinning and fills to the selected water level and continues washing with the selected cycle.



CATALYST CLEANING ACTION™ RECIRCULATION SYSTEM

QUIET PAK™

The QUIET PAK™ System is designed to reduce water sounds and mechanical noises. The cabinet and base are insulated with sound-dampening materials over which an additional tub wrap is added for superior vibration and sound-dampening characteristics.



BLEACH VENTURI


The bleach venturi causes a siphoning action to draw bleach from the bleach dispenser. Water passing across the venturi opening creates a low pressure area behind the venturi pulling the bleach into the passing water flow.



TUB RING



PRESSURE TRANSDUCER



The water level transducer is located at the left end of the console area and is used to regulate the level of wash and rinse water in the tub. The electronic pressure transducer converts air pressure created in the pressure dome to a low voltage square wave signal. The microcomputer on the control board reads the signal directly. The microcomputer then translates the frequency into inches of water. This is then compared to the setting selected by the user during the wash cycle.

The transducer also contains a mechanical overfill switch in the same transducer body. This operates the same as the standard pressure switch. The overfill operates (opens) when the water level in the tub is beyond the standard high fill level (flood level).


OUT OF BALANCE SWITCH

The Out of Balance Switch controls the motor operation during the Catalyst Cleaning portion of the cycle, as well as during the spin. If an out of balance condition occurs during Catalyst Clean, the motor circuit is interrupted. The motor will stop momentarily to allow the load to settle, then restart. If the Out of Balance Switch is actuated four times, the Electronic Control will skip the Catalyst Clean cycle and jump to the wash increment.

If an out of balance condition occurs during spin, the motor circuit will again be interrupted momentarily to allow the load to settle. If the Out of Balance switch is actuated four times during the spin cycle, the cycle will stop and the control will display "OB".



BALANCE RING




Balance Ring shown upside-down

The Balance Ring is a special dual chambered ring with the traditional water ballast in the top chamber and an oil charge with steel balls in the lower chamber. The additional ballast is required to counteract the clothing load during the Catalyst Cleaning mode.

The ring is attached to the spin basket and is not available as a separate component.

The oil chamber contains approximately 320 cc of oil and should be treated as any other oil when disposal becomes necessary.

DISPENSERS



Bleach, Detergent and Fabric Softener dispensers are provided to allow the consumer to load the laundry additives with the clothing load. The dispensers allow the additives to be introduced to the laundry load at the proper time in the cycle.

A diverter is molded into the tub ring to push the dry clothing into the basket during the Catalyst Cleaning portion of the cycle.

INLET AND DISPENSER VALVE ASSEMBLY

**Bleach Dispenser Outlet Valve
(with Back-Flow Restrictor)**

**Fabric Softener Dispenser
Outlet Valve**

**Detergent Dispenser
Outlet Valve**

**Fresh Water Outlet Valve
(with Back-Flow Restrictor
and Thermistor)**

Cold Water Inlet Valve

Hot Water Inlet Valve



A new inlet valve assembly is used on this model. It is made up of the hot and cold inlet valves and the dispenser valves that operate the dispensers as well as the fresh water fill. Also included is the thermistor used with the AccuWash option to control incoming water temperature.

HIDDEN LID SWITCH



A hidden lid switch is used on the Catalyst Clean model. It is located under the right rear corner of the washer top and is actuated by the lid hinge.

Section Two

THEORY OF OPERATION CONTROL PANEL



Fig. 2-1

OPERATING THE CLOTHES WASHER

Choosing Cycles

Use the SELECT CYCLE keypads to choose the wash cycle for the type of fabrics being washed.



Fig. 2-2

GENERAL INFORMATION

The Electronic Control allows the consumer to add or subtract agitation time in all cycles.

- For most loads, use the time recommended in the preset settings.
- For heavy soil and sturdy fabrics, more time can be used.
- For light soil and delicate fabrics, less time can be used.

HEAVY DUTY

This cycle provides between 4 and 18 minutes of wash time for loads of sturdy, colorfast fabrics such as work clothes. Cycle combines fast speed agitation and fast spin speeds. The preset wash time for this cycle is 12 minutes.

WHITEST WHITES

Detergent and bleach are dispensed at the proper time for the best possible performance.

This cycle introduces liquid chlorine bleach sooner to the load than the other cycles for improved whitening of heavily soiled white fabrics. The default motor speeds for agitation and spin are both high speed. The preset wash time for this cycle is 10 minutes.

NORMAL

This cycle provides between 4 and 18 minutes of wash time for normally soiled cottons and linens. This cycle combines high speed agitation with a step down to medium speed and high speed spin. The preset wash time for this cycle is 10 minutes.

PERMANENT PRESS

The PERMANENT PRESS Cycle includes a load cool-down process that reduces wrinkling compared to other cycles.

To begin the cool-down process, the washer will perform a ½ tub drain, pause, and then fill at the selected rinse temperature. This cools the load before the first spin.

This cycle provides between 4 and 18 minutes of wash time for use with no-iron fabrics, sports shirts, blouses and cotton slacks. This cycle includes a deep rinse at fast speed agitation with “stepped” spin speeds (spins start at an extra-slow speed before finishing at a low speed to reduce wrinkling). The preset wash time for this cycle is 8 minutes.

QUICK WASH

This cycle begins with a continuous spray of water and detergent mixture as the load is spun at low speed. This is followed by 4 to 10 minutes of wash time for small, lightly soiled loads that need refreshing. The preset wash time for this cycle is 4 minutes.

EXTRA DELICATE

This cycle provides between 4 and 18 minutes of extra-low speed agitation for sheer fabrics and lingerie. The agitation is followed by a deep rinse and a slow spin speed. The preset wash time for this cycle is 6 minutes.

HAND WASH

The wash cycle starts with a continuous spray of water and detergent mixture as the load is spun at low speed. This is followed by a normal tub fill to the selected level. This is followed with between 4 and 18 minutes of wash time with intermittent periods of extra-slow agitation and soaking. The preset wash time for this cycle is 4 minutes.

FAVORITE CYCLE

This cycle allows the user to store a customized wash cycle.

To set a FAVORITE WASH cycle:

1. Select a Wash Cycle
2. Select the desired Options
3. Select the desired Modifiers
4. Press and hold FAVORITE CYCLE until a “beep” sounds (approximately three (3) seconds.)

The Favorite Cycle is now stored for future use. To reuse, press the FAVORITE CYCLE keypad and press START.

Choosing Options

Use the OPTIONS control to select the desired options for the wash cycle.



CATALYST CLEANING™

CATALYST CLEANING™ allows detergent to soak and penetrate the entire load giving improved stain and soil removal. This option will last one (1) to five (5) minutes depending on the cycle selected. The washer then stops spinning and fills to the selected water level and continues washing with the selected cycle.

SOAK

This option should be used for set-in stains and soils that needs extra time for removal. The SOAK option can be used in two (2) different ways:

- Choosing SOAK with a cycle gives a brief period of soak added to the wash cycle.
- Choosing SOAK alone gives up to 60 minutes of soak time.

RINSE OPTIONS

STAND ALONE CYCLES:

- **DRAIN/SPIN** - This cycle will drain the water and spin the load. The spin will be 6 minutes at high speed.
- **RINSE/SPIN** - This option will provide a deep rinse with low-speed agitation followed by a drain and a two-step spin. (Spin begins at high-speed and steps down to low-speed. The time display will include an estimate of how long it will take to fill and drain the water.

SELECTED WITH ANOTHER CYCLE:

- **DRAIN/SPIN**-This option will provide an additional six minutes to the spin. The spin speed will depend on the cycle selected.
- **RINSE/SPIN**-This option provides a second deep rinse with the same water temperature as selected for the first rinse. A second rinse can be added to any main wash cycle.

Choosing Modifiers

These controls allow the selection of desired Water Level, Wash and Rinse Temperatures, Agitation Time, or End of Cycle Signal volume for your wash cycle.

SOIL LEVEL


The Soil Level option will add or subtract agitation time, depending on whether “more” or “less” soil is selected.

WATER LEVEL

Up to five (5) different water levels can be selected ranging from SMALL LOAD to LARGE LOAD. In most cycles, reducing the water level will result in the motor operating at a slower agitation speed. See chart on page 9.

WASH/RINSE TEMP CONTROL

This allows the selection of four (4) different wash and rinse water temperature combinations based on the type of load being washed.



SELECTING WATER TEMPERATURE		
Wash Water Temperature	Suggested Fabrics	Comments
HOT 111°F (44°C) or above	<ul style="list-style-type: none"> Work clothes Sturdy whites/colorfast pastels Diapers 	<ul style="list-style-type: none"> Best cleaning for heavily soiled items Removes oils, perspiration, greasy soils and stains Reverts graying or yellowing
WARM 90° - 110°F (32° - 43°C)	<ul style="list-style-type: none"> Dark/non-colorfast colors Permanent press items Nylon, polyester, acrylics silk, woolens Knits/delicate 	<ul style="list-style-type: none"> Best for moderately soiled to lightly soiled items Safe for most fabrics Less fading and dye bleeding Reduces wrinkling
COLD* 70° - 90°F (21° - 32°C)	<ul style="list-style-type: none"> Extra-sensitive colors Non-colorfast items Handwashables 	<ul style="list-style-type: none"> Best for very lightly soiled items Saves hot water

* In wash water temperatures colder than 70°F (21°C), detergents do not dissolve well and soils may be difficult to remove. Some fabrics may retain wear wrinkles and have increased pilling - the formation of small lint-like balls on the surface of the garment. Pilling is the natural result of wearing and washing of a garment.

AUTOMATIC TEMPERATURE CONTROL, (ACCUWASH)

AUTOMATIC TEMPERATURE CONTROL (ATC) electronically senses and maintains a uniform water temperature by regulating incoming hot and cold water.

- Even in cold wash, some hot water is introduced into the washer to maintain a temperature of approximately 75°F (24°C).
- Warm wash is regulated at approximately 100°F (32°C).
- Warm rinse is regulated at approximately 75°F (24°C), whether AccuWash is selected or not.
- The second fill in the PERMANENT PRESS Cycle is for cooling the load and uses unregulated cold water.

ADJUSTABLE CYCLE SIGNAL

A tone will sound at the end of the wash cycle. The sound level of this tone can be adjusted from LOUD to OFF by pressing the SIGNAL keypad.




Operating Controls

Press the START keypad to start the washer after a cycle has been selected.

Press the PAUSE/CANCEL keypad to pause or stop the washer at any time.

Press the START keypad to complete the cycle from where it was stopped.

Press the PAUSE/CANCEL keypad twice to turn the washer off.



WASHER TOP FEATURES



**Bleach
Dispenser**

**Fabric
Softener
Dispenser**

**Clothing
Diverter**

**Splash
Shield**

**Detergent
Dispenser**

OPERATIONAL CYCLES

MODIFIERS - OPTIONS D = Default S = Selectable BLANK = Not Available	CYCLES									
	HEAVY DUTY	NORMAL	P. PRESS/CASUAL	EXTRA DELICATE	HAND WASH	QUICK WASH	WHITEST WHITES	SOAK	SPIN	RINSE/SPIN
WATER LEVEL										
Super Plus (5)	D	D	D	S	S	S	D	D		D
Med. High (4)	S	S	S	S	S	S	S	S		S
Medium (3)	S	S	S	S	S	D	S	S		S
Med. Small (2)	S	S	S	D	D	S	S	S		S
Small (1)	S	S	S	S	S	S	S	S		S
WASH/RINSE TEMP										
Hot/Cold	S	S	S	S	S	S	D	S		S
Warm/Warm	S	S	S	S	S	D	S	S		S
Warm/Cold	D	D	D	D	S	S	S	D		D
Cold/Cold	S	S	S	S	D	S	S	S		S
SOIL LEVEL										
More	D	S	S	S	S	S	S	S		
Normal	S	D	D	D	D	D	D	D		
Less	S	S	S	S	S	S	S	S		
SOAK 12 min. only	S	S	S	S	S	S	S			
CATALYST CLEAN	D	S	S	S	on	on	D	S		
AUTO TEMP.	D	D	D	D	D	D	D	D		D
RINSE OPT., 2nd RINSE	S	S	S	S	S	S	D	S		
EXTRA SPIN OPT.	S	S	S	S	S	S	S	S		

NOTES:

- If Rinse/Spin is added to any cycle, it becomes an Extra Rinse
- If Spin Only is added to any cycle, it becomes an additional 4 minutes of spin.
- Soak will provide both some agitation and spin.
- Catalyst Clean is selectable in all cycles except Quick Wash and Hand Wash.

AGITATE SPEEDS

CYCLES	WATER LEVELS				
	SUPER +	4	MEDIUM	2	SMALL
HEAVY DUTY	Hi	Hi	Hi	Med	Med
NORMAL (see notes)	4 Hi, Med / 1 Hi, Med	4 Hi, Med / 1 Hi, Med	Med	Low	Low
PERM PRESS/CASUAL	Med	Med	Med	Low	Low
EXTRA DELICATE	Low	Low	Low	Low	Low
QUICK WASH	Med	Med	Med	Low	Low
HAND WASH	Intermit	Intermit	Intermit	Intermit	Intermit
WHITEST WHITES	Hi	Hi	Hi	Med	Med
SOAK	Med	Med	Med	Med	Med
RINSE/SPIN	Med	Med	Med	Med	Med
SPIN ONLY	NA	NA	NA	NA	NA

NOTES:

- Speeds are dependent on water level and cycle selected.
- Defaults are shaded areas.
- **4 Hi, Med/1 Hi, Med** = 1st 4 minutes of core wash agitate = Hi, then remaining core wash agitate = Med. Also 1st 1 minute of rinse agitate = Hi, then remaining rinse agitate = Med.
- **Intermit** = Intermittent agitate at low speed.

SPIN SPEEDS

CYCLES	SPIN SPEED
1 - HEAVY	640
2 - REGULAR	640
3 - PERM PRESS	420
4 - DELICATE	420
5 - HAND WASH	420
6 - QUICK WASH	640
7 - WHITEST WHITES	640
8 - SOAK	640
9 - RINSE/SPIN	NA
10 - SPIN ONLY	NA

NOTES:

- All Catalyst Cleaning Action takes place at 420.

-- NOTES --

Section Three
COMPONENT ACCESS
COMPONENT LOCATION




Fig. 1

ACCESSING COMPONENTS IN THE CONSOLE

1. Disconnect the power supply to the washer.
2. Remove the two (2) Phillips Head screws securing the lower left and right rear corners of the console to the washer top. (Fig. 2)
3. Tilt the console back on the hinges that secure the top of the console to the washer back.

Fig. 2



All components in the console are now accessible for service.

IMPORTANT SERVICING POINTS

Electrostatic Discharge (ESD) Sensitive Electronics

Do not open the package containing the Electronic Printed Circuit Board until it is time to install it.

ESD may damage or weaken the electronic board.

- Use an anti-static wrist strap. Connect wrist strap to a green ground connection point or unpainted metal on the appliance.

OR

Touch your finger repeatedly to a green ground connection point or unpainted metal on the appliance.

- Avoid touching electronic parts or terminal contacts; handle the electronic board by the edges only.

Removing the Electronic Control Board

The Electronic Control Board is located in the center of the console area.

1. Disconnect the four (4) wiring harness plugs and two (2) ribbon connectors from the electronic control board. (Fig. 3)
2. Remove the hex-head screw securing the electronic control board to the control bracket.





Fig. 3

3. To remove the Electronic Control Board from the control bracket, squeeze the sides of both mounting clips and pull up on the entire assembly. (*Fig. 4*)

Fig. 4



ACCESSING COMPONENTS IN THE WASHER CABINET

Components inside the washer cabinet can be accessed by completely removing the outer cabinet as one unit. Refer to *Figure 5* for the following instructions.

1. Remove the console mounting screws and tilt the console into the service position.
2. Unplug the lid switch harness connector from the receptacle in the washer top.
3. Remove the cabinet mounting clips by placing the flat blade of a screwdriver in the clip as shown in *Figure 5, Inset 1*.




Fig. 5

4. Rotate the access cover on the washer top clockwise to expose the hose assemblies underneath. (*Fig. 6*)
5. Disconnect the bleach dispenser venturi hoses and the detergent and fabric softener inlet hoses as indicated in *Figure 6*.



Fig. 6

6. Pull the inner basket forward, to avoid damage to the tub ring, splash guard and shield. Remove the cabinet by tilting it forward and pulling it away from the washer. (*Fig. 7*)





Fig. 7

NOTE: If the washer must be operated with the cabinet removed, the dispenser hoses previously disconnected must be held into the basket to avoid water spray. Install a jumper wire (Part No. 285784) in the lid switch harness connector as shown.

IMPORTANT: Use extreme caution when operating the washer with the cabinet removed as electrical shock may occur.



! IMPORTANT

For the purposes of illustration certain components are shown without protective covers or shields. If any of these components are serviced or replaced the protective covers or shields **MUST** be reinstalled.

Removing Components Attached to the Washer Top

Components attached to the underside of the washer top (*Fig. 8*) are:

- Bleach and Fabric Softener Dispenser Assembly
- Detergent Dispenser
- Hidden Lid Switch




Fig. 8

Removing the Bleach and Fabric Softener Dispenser Assembly

1. Disconnect the two (2) inlet hoses from the bleach and fabric softener dispenser assembly.
2. Disengage the tabs around the perimeter of the assembly from the washer top and remove the assembly from the topside of the washer top.

Removing the Detergent Dispenser

1. Disconnect the inlet hose from the detergent dispenser cup.
2. Disengage the four (4) locking tabs from the washer top and remove the detergent dispenser cup from the topside of the washer top.

Removing the Hidden Lid Switch

1. Remove the two (2) Phillips-head screws securing the hidden lid switch to the washer top. (*Fig. 9*)
2. Disengage the two (2) locking tabs that secure the lid switch in place.
3. Disconnect the lid switch plug from the connector on the underside of the washer top.
4. Remove the lid switch from the underside of the washer top.
5. To reinstall the switch, the lid **MUST** be in the open position.




Fig. 9

Removing Components Attached to the Feature Panel

Components attached to the rear feature panel include:

- Water Inlet Valve Assembly
- Valve Assembly Shield
- Out-of-Balance Switch
- Recirculation Pressure Dome
- Recirculation Diverter Valve

Removing the Water Inlet Valve Assembly

The Water Inlet Valve Assembly is attached to the left inside surface of the rear feature panel. Refer to *Figure 10* for the following procedures.

NOTE: The Fresh Water Outlet is equipped with a Thermistor and a Back-Flow Restrictor (Duck Bill). The Bleach Outlet is equipped with a Duck Bill as well. **When servicing or replacing a valve assembly, make sure these items are reinstalled.**




Fig. 10

1. Shut off the water supply and disconnect the hot and cold inlet hoses.
2. Remove the two (2) hex-head screws securing the valve assembly to the feature panel. (Fig. 11) The assembly will remain in place until it is lifted slightly.
3. Disconnect all wiring harness plugs from the four (4) outlet valve solenoids and the two inlet solenoids, making note of their locations.
4. Disconnect the four (4) outlet hoses from the four (4) outlets.
5. Lift the assembly to disengage the mounting bracket ears from the slots in the feature panel and remove the assembly.



Fig. 11

Removing the Out-of-Balance Switch

The Out-of-Balance Switch is located on the inside surface of the feature panel.

1. Reach into the bottom of the plastic protective cover of the Out-of-Balance Switch and disconnect the wiring harness plug from the switch terminals.
2. Remove the hex-head screw on the outside surface of the feature panel. (Fig. 12)
3. Slide the Out-of-Balance Switch so the tabs of the mounting bracket disengage from the key slots as show in *Figure 12* and remove the switch assembly.

NOTE: The Service Replacement Out-of-Balance Switch is equipped with a clear plastic protective cover. **This MUST be installed with the switch.** (Fig. 13)




Fig. 12

SLIDE TO LEFT TO
DISENGAGE TABS

SCREW



Fig. 13

Servicing the Catalyst Cleaning Action™ Recirculation System

Figure 17 illustrates the various components of the Catalyst Cleaning Action™ recirculation system. These components are:

- Pump
- Diverter Valve
- Recirculation Pressure Dome
- Recirculation Pressure Switch
- Recirculation Spray Inlet (part of Tub Ring)




Fig. 17

NOTE: The Diverter Valve is equipped with a plastic protective cover. **If the diverter valve is serviced or replaced the protective cover MUST be reinstalled.**

-- NOTES --

Section Four

COMPONENT TESTING AND DIAGNOSIS

SERVICE DIAGNOSTIC TESTS

The control must be in the OFF state before pressing the keys to initiate the diagnostic tests. To start the test routine, press the following key pads in this sequence:

WASH/RINSE > ACCUWASH > WASH/RINSE > ACCUWASH

within five (5) seconds. The LED will display DT The required diagnostic test(s) can now be activated.

Any diagnostic test can be stopped by pressing the STOP/CANCEL keypad. Diagnostic test will self-terminate after running for about three (3) minutes.

COMPONENT	KEY PAD	DISPLAY	CONTROL ACTION
Water Inlet and Dispenser Valve Test	HEAVY DUTY	T1	No Valve ON
	repeat	T1	All valves ON
	repeat	T1	Cold, Fabric Softener and Fresh valves ON
	repeat	T1	Hot, Detergent and Bleach valves ON
	repeat	T1	No valves ON
	repeat	T1	Exits test
Recirculation Pressure Switch Test <i>(NOTE: Empty the tub before continuing with this test.)</i>	WHITEST WHITES	Oscillates between T2 and E R	The washer starts to fill through the Hot, Cold and Fresh water valves. Water is recirculating and the basket spins at med. speed. the Recirculation Pressure switch should be closed. NOTE: If "E R" is displayed immediately and persists, the recirculation pressure switch or tubing may have failed, or the pump is not recirculating water. As the water level approaches the switching point, the display may oscillate between "T 2" or "E R" a few times if the pressure switch is operating properly.
		E R	Once the proper level of water is reached for recirculation, the valve turns off and "E R" is displayed. The basket continues to spin at med. speed and water recirculates. NOTE: If "T 2" is displayed, there is a failure. Replace the recirculation switch.
	repeat	T2	The basket continues to spin at med. speed and water recirculates
	repeat	T2	Spinning and recirculation stop
	repeat	T2	Exit test

SERVICE DIAGNOSTIC TESTS


COMPONENT	KEY PAD	DISPLAY	CONTROL ACTION
Pressure Transducer/ Agitate Test	NORMAL	ER	Hot, cold and fresh water valves are on until a low water level is reached, and the small load water level LED comes on.
		T3	Agitation occurs at high speed. The small load LED is on.
	repeat	T3	Agitation occurs at med. speed. The small load LED is on.
	repeat	T3	Agitation occurs at low speed. The small load LED is on.
	repeat	T3	Agitation stops, and the large load water level LED comes on.
	repeat	T3	Hot, cold and fresh water valves come on. The large load water level LED is on.
	repeat	ER	“ ER ” appears when water reaches full level. Motor agitates at low speed and the large load water level LED is on.
	repeat	T3	Agitation stops. The large load water level LED is on.
		T3	Exit test
Neutral Drain /Spin Test	PERMANENT PRESS	T4	Motor drains at high speed
	repeat	T4	Motor drains at med speed
	repeat	T4	Motor drains at low speed
	repeat	T4	No action
	repeat	T4	Exit test

CONSOLE SWITCHES AND INDICATOR TEST

To start the test press the following touchpad sequence within five (5) seconds:

WASH/RINSE > ACCUWASH > WASH/RINSE > ACCUWASH

- Press the START pad. All LEDs should light and the display should show “88”.
- Each touchpad controls the LED next to it.



ERROR CODES

DISPLAY	EXPLANATION
FF (Fill Failure)	<p>If the transducer signals a high or a low water level for more than 16 seconds the washer will shut off and FF will flash.</p> <ul style="list-style-type: none"> • Press the RINSE OPTIONS button and select DRAIN/SPIN to drain washer. • Check the water level transducer hose and wire connections. • Also check the pressure dome hose to be sure they are properly connected. • Check the water level transducer, see TEST #7.
LF (Long Fill)	<p>Flashes when the fill time exceeds 1 hour or the water valve(s) are turned off. Press PAUSE/CANCEL to clear display.</p>
LD (Long Drain)	<p>Flashes if it takes longer than 1 hour to pump out water down to a reset level (approx. 4 inches). Press PAUSE/CANCEL to clear display.</p>
OL (Open Lid)	<p>Flashes if the lid is opened during a spin cycle.</p> <ul style="list-style-type: none"> • Close lid or press PAUSE/CANCEL to clear display. • If OL continues to flash, check lid switch.
OB (Out-Of-Balance)	<p>Flashes when washer basket exceeds out-of-balance limits during spin. The washer automatically attempts the spin cycle 4 times when an out-of-balance load is detected. If the clothes are not redistributed enough after these attempts, OB is displayed and the washer goes into the STANDBY mode.</p> <ul style="list-style-type: none"> • To clear display, evenly distribute the clothes load and close lid. • If OB continues to flash, check out-of-balance solenoid switch, see Test No. 3.
F 1 (Spin/Agitate Failure)	<p>Flashes when basket has spun in error during the agitation portion of the cycle. Press PAUSE/CANCEL to clear display.</p> <ul style="list-style-type: none"> • Select any cycle with agitation. Once agitation begins, "F 1" should not flash, and washer should not spin during agitation. • If "F 1" continues to flash, replace recirculation pressure switch and make sure there are no kinks or blockages in the tubing. • Select any cycle with agitation. Once agitation begins, "F 1" should not flash. If "F 1" continues to flash, replace the control board, see page 8.
F 3 (Lid Switch Failure)	<p>Flashes if the lid is NOT opened after the cycle was completed. The electronic control board must detect that PAUSE/CANCEL was pressed during a cycle or the lid was opened at least once at the end of any cycle. This is continually tested to ensure proper lid switch operation. If "F 3" is flashing, check continuity of the lid switch.</p> <ul style="list-style-type: none"> • With the lid closed, lid switch contacts should be closed. • With the lid open, lid switch contacts should be open. • If the lid switch has failed, replace it. • If the lid switch is good, replace the electronic control board.

TROUBLESHOOTING TEST PROCEDURES

Test #1 - 120 VAC Electrical Supply

Check for 110-125 VAC to the control board.

1. With the washer off but connected to the AC outlet, measure the AC voltage between Pins 2 and 1 at connector P5.
2. If 110-125 VAC is present, continue with the remaining Troubleshooting Tests as needed. If voltage is not present, check circuit breaker or fuse box, power cord connection at outlet and washer.

Test #2 - Water Inlet & Dispenser Solenoid Valve Test

This test checks for 110 - 125 VAC to these valves, the electrical connections to the valves, and the valves themselves.

A: Check the relays and electrical connections to the valves.

1. See the *Service Tests* and perform the **Water Inlet and Dispenser Valve Test**. Each step in the test activates a group of valves. The table shows where voltage measurements are to be checked for each valve. The voltage should be from 110 VAC to 125 VAC.

Connector P6	Connector P5	FUNCTION
Pin # 1	Pin # 2	Cold water valve
Pin # 2	Pin # 2	Hot water valve
Pin # 5	Pin # 2	Fresh water valve
Pin # 3	Pin # 2	Detergent dispense valve
Pin # 4	Pin # 2	Fabric softener dispense valve
Pin # 6	Pin # 2	Bleach dispense valve
Pin # 9	Pin # 2	Drain recirculation valve

2. If no voltage is present at any of these test points and the voltage at the wall outlet is normal (See Test No. 1), the control board has a faulty relay. Replace the control board. If this test is OK, go to **B**.

B: Check the individual solenoid valves.

1. Unplug the washer and disconnect connectors P5 and P6 from the control board before checking the resistance. Make the checks at contacts shown.

SOLENOID	RESISTANCE	MEASURE BETWEEN
Bleach Valve	800 - 1200Ω	P5 contact 2 P6 contact 6 WH LBU
Fresh Valve	600 - 1000Ω	P5 contact 2 P6 contact 5 WH WH/BU
Fabric Softener Valve	800 - 1200Ω	P5 contact 2 P6 contact 4 WH OR/BK
Detergent Valve	800 - 1200Ω	P5 contact 2 P6 contact 3 WH PK/BK
Hot Water Valve	800 - 1200Ω	P5 contact 2 P6 contact 2 WH TN/RD
Cold Water Valve	800 - 1200Ω	P5 contact 2 P6 contact 1 WH Y/RD

- If the resistance is outside of range, replace the valve assembly.

Test #3 - Off-Balance Solenoid Switch Test

- Unplug the washer and disconnect connectors P5 and P6 from the control board before checking the resistance. Make the checks at contacts shown. **NOTE:** Off balance arm must be depressed to read solenoid resistance. Move basket to rear of unit to actuate arm.

SOLENOID	RESISTANCE	MEASURE BETWEEN
Off Balance Coil	1200Ω	Lid Sw Harness P5 contact 3 GY/WH GY

Test #4. Motor Control System Test

This test checks that the appropriate relays are delivering voltage to the motor and that the wiring connections from the control board to the motor are good.

- See the **Pressure Transducer / Agitate Test** in the *Service Diagnostic Tests* table. As test progresses, 110 - 125 VAC should be measured across the following test points for each agitation speed.

High Speed	Across P9-2 and P7-2
Medium Speed	Across P9-2 and P9-1
Low Speed	Across P9-2 and P7-4
- If 110 - 125 VAC **is not** measured across any of the points, replace the control board.
- If 110 - 125 VAC **is** measured across these points but the motor does not run, go to the motor test. This test will check the wiring to the motor and the motor.

Alternate Motor Test

- Unplug the washer. Check resistance of Low, Med, and High speed motor windings as shown in the chart. **Note:** The start winding coil must be checked at the motor.

WINDING	RESISTANCE	MEASURE BETWEEN
Low	2.6Ω	P7 - 4 P9 - 2 WH/OR WH/BK
Medium	1.5Ω	P7 - 1 P9 - 2 OR WH/BK
High	2.3Ω	P7 - 2 P9 - 2 WH/VT WH/BK
Start	5.1Ω	Measured at the motor across the RD and YL colored wires.

- If the measurement shows infinite ohms, there is either an open circuit in the motor winding or in the connection between the control board and the motor. To locate the open circuit, measure the resistance at the motor instead of across P7 and P9.
- If the resistance is still infinite, replace the motor.
- If the resistance at the motor test OK, there is an open circuit in the wiring between the motor and control board. Repair or replace the wiring harness.

Test #5 - Console Touch Switches and Indicator Test

Refer to the Service Diagnostic Tests and run the Console Switches and Indicator Test routine.

Start the test by pressing the *Start* button.

1. **No LEDs light up**
 - a) Visually check that connectors P3 and P4 are inserted all the way into the control board.
 - b) If these connections are good, remove P3 and P4 from the control board while the power is still on. Check the DC supply voltage to the indicator and switch assembly by measuring the voltage between P3-4 (black lead of meter) and the following points:
 - P3-10
 - P3-11
 - P3-12
 - P3-13
 - P3-14
 - P4-2
 - P4-3
 - c) If at least 3 VDC is measured, replace the key switch/console assembly.

2. **A group of LEDs do not light up**
 - a) A “group” or combination of LEDs share a common connection. If this connection is open, all of the LEDs in the group will be disabled.
 - b) Replace the key switch/console assembly.

3. **A single LED is OFF**
 - a) Press the touch switch button that is associated with the LED several times.
 - b) If the LED does not light up, the LED has failed.
 - c) Replace the key switch/console assembly.

4. **Beeps are NOT heard**

If beeps are not heard but associated LED(s) turn on and off, it is possible that the beeper circuit has failed or that the control board has failed. **Before replacing the control board, check for proper touchpad functioning:**

- a. Disconnect the power cord from the outlet.
- b. Remove connector P3 and P4 from the microcomputer board. Using the table in the tech sheet, measure the resistance across the switch when the switch button is pressed. The meter must be connected with the proper polarity.
 - **If using an analog readout:** the resistance reading should go from infinity (open circuit) down to about 10 or 20 ohms.
 - **If using a digital readout:** the resistance reading should go from infinity down to about 2 megohms - 4 megohms. If available you could use the “diode test” function of a digital meter, which will give a voltage of about 1.2 VDC during the test.
- c. If any switches fail, this test, replace the key switch/console assembly.
- d. If they test OK, replace the control board.

TOUCHPAD	+ LEAD	- LEAD
HEAVY DUTY	P3-1	P3-4
WHITEST WHITES	P3-3	P3-5
NORMAL	P3-2	P3-4
PERM PRESS	P3-3	P3-4
QUICK WASH	P3-1	P3-6
EXTRA DELICATE	P3-1	P3-5
HAND WASH	P3-2	P3-5
SOAK	P3-2	P3-7
SPIN	P3-3	P3-8
RINSE/SPIN	P3-3	P3-6
CATALYST	P3-1	P3-7
START	P3-1	P4-5
PAUSE/CANCEL	P3-2	P4-5
END OF CYCLE	P3-3	P4-5
AUTO TEMP.	P3-1	P4-6
LOAD SIZE	P3-3	P3-7
WASH/RINSE TEMP	P3-1	P3-8
FAVORITE CYCLE	P3-2	P3-6
SOIL LEVEL	P3-2	P3-8

5. **No washer function is activated when a particular touchpad is pressed.**

If the associated LEDs do light up, it is possible that the control board has failed. Check touchpad functioning before replacing control board.

Test #6 - Automatic Temperature Control (ATC) Test

This test checks the water inlet relays, the temperature sensor, and the control board.

A: Test the fill valves

1. Check that the hot and cold water valves are working. Use the procedure in **Test #2**.
Note: This test **MUST** be done with the Automatic Temperature Control **off**.
2. If working properly, go to **B**.

B: Test the temperature sensor

1. Turn on the Automatic Temperature Control feature.
2. Set the water level setting to the “Low” setting. Use the WASH/RINSE TEMP selector button and set the Wash water temperature to “Warm”.
3. Press the “Regular” or “Heavy Duty” cycle.
4. Press “Start”. After the tub fills, press the “Stop/Pause” button. Measure the temperature of the water. For the Warm setting, the temperature range should be 90 - 110 degrees F which indicates proper operation.
5. If the temperature is not in this range, check the Automatic Temperature Control sensor as follows:
 - Remove connector P5 from the microcomputer board.
 - Measure the resistance between P5-5 and P5-4 in the connector. The resistance should be between 74 kΩ and 24 kΩ. If not, check for continuity between the connector and the sensor. If continuity is good, replace the temperature sensor/inlet valve assembly.

THERMISTOR RESISTANCE CHART	
Temperature Degrees (F)	Resistance (Ohms)
40	126k - 135k
50	97k - 102k
60	75k - 78k
70	58k - 61k
80	46k - 47k
90	36k - 37k
100	28k - 30k
110	23k - 24k
120	18k - 19k
130	15k - 16k
140	12k - 13k
150	10k - 11k

C: If system passes Steps A & B - Replace the control board.

Test #7 - Water Level Transducer Test

The **FF** diagnostic code is displayed on console or, the customer complains of unexpected water levels.

Customer complains of unexpected water levels.

A. Verify the complaint with the following procedure by checking for proper water level fills. Use the table below:

WATER LEVEL SELECTION	LEVEL IN BASKET (inches)
Large Load	14 ±½
Medium Load	11½ ±½
Small Load	9 ±½

If the complaint is not verified, do the Pressure Transducer/Agitator Test in the Service Diagnostic Test Table. Note the results of the first steps and the third from the last step of the routine.

If the complaint is verified:

B. Check that the hose connections between the pressure transducer in the console and the pressure dome attached to the tub are OK. If they are, do the following test:

1. With AC power on and the tub empty, measure the DC voltage between pins P1-1 and P1-2 while the connector is still attached to the control board.
2. If the voltage is between 2 and 3 VDC, replace the control board. If the voltage is outside of this range, check the harness connections.
3. If these connections are OK, replace the water level transducer.

FF Diagnostic Code is displayed.

Perform the same procedures as described in B above.

Test #8 - Recirculation Pressure Switch Test

Perform Recirculation Pressure Switch Test in the *Service Diagnostic Test table.*


1. If water recirculation does not take place, do the following test:
2. Connect a voltmeter (set to measure AC volts) across P5-4 and P5-2. At the times in the service diagnostic routine where recirculation should take place, the AC voltage reading should go from a reading of about 120 VAC down to about 0 VAC.
3. If this does not happen, replace the drain/recirculation pressure switch. NOTE: When the tub is empty, the drain/recirculation pressure switch is closed and line voltage (125 VAC) must be measured across P5-4 and P5-2. If test fails, replace the drain/recirculation pressure switch.
4. If test shows that the drain/recirculation pressure switch is OK, the problem is either in the electronic control board or the drain/recirculation solenoid valve.
 - Unlike other solenoids, the coil resistance in the drain/recirculation solenoid valve can not be measured. Replace the solenoid.
 - If the washer still does not recirculate, replace the electronic control board.

-- NOTES --

Section Five

TECH TIPS

WIRING DIAGRAM




WARRANTY INFORMATION

- 1 year Parts and Labor - entire unit
- 2-5 yr. Parts only - Gearcase assembly
 - Top and Lid rust
 - Electronic Controls-includes Keyswitch
- 2-10yr Parts only - Outer tub
- Lifetime Parts only- White porcelain spin basket for chipping or rust.

MODEL/SERIAL NUMBER PLATE LOCATOR

The Model/Serial Number Plate is located at the back of the opening of the washer top underneath the lid.



MODEL NUMBER DESIGNATOR

PRODUCT GROUP	G	S	X	9	8	8	5	J	Q	0
G = WHIRLPOOL GOLD										
S = SUPER CAPACITY PLUS										
X = CATALYST CYCLES										
SPEED COMBINATIONS										
TEMPERATURES										
WATER LEVELS										
YEAR OF INTRODUCTION										
COLOR										
ENGINEERING CHANGES (NUMERIC)										

SERIAL NUMBER DESIGNATOR

SERIAL NUMBER	C	K	36	50001
MANUFACTURING SITE				
C = Clyde, OH				
YEAR OF MANUFACTURE				
K = 2000				
WEEK OF MANUFACTURE				
PRODUCT SEQUENCE NUMBER				

-- NOTES --

-- NOTES --

PRODUCT SPECIFICATIONS
AND
WARRANTY INFORMATION SOURCES

IN THE UNITED STATES:

FOR PRODUCT SPECIFICATIONS AND WARRANTY INFORMATION CALL:

FOR WHIRLPOOL PRODUCTS: 1-800-253-1301
FOR KITCHENAID PRODUCTS: 1-800-422-1230
FOR ROPER PRODUCTS: 1-800-447-6737

FOR TECHNICAL ASSISTANCE WHILE AT THE CUSTOMER'S HOME CALL:

THE TECHNICAL ASSISTANCE LINE: 1-800-253-2870

HAVE YOUR STORE NUMBER READY TO IDENTIFY YOU AS AN AUTHORIZED SERVICER

FOR LITERATURE ORDERS:

PHONE #: 1-800-851-4605

IN CANADA:

FOR PRODUCT SPECIFICATIONS AND WARRANTY INFORMATION CALL:

1-800-461-5681

FOR TECHNICAL ASSISTANCE WHILE AT THE CUSTOMER'S HOME CALL:

THE TECHNICAL ASSISTANCE LINE: 1-800-488-4791

HAVE YOUR STORE NUMBER READY TO IDENTIFY YOU AS AN AUTHORIZED SERVICER

