3-1) Refrigerator Door
3-2) Door Switch In Refrigerator
3-3) Door Gasket
3-4) Door Handle
3-5) Refrigerator Light
3-6) Internal Water Dispenser
3-7) Spill Proof Glass Shelf
3-8) Vegetable & Fruit Drawers
3-9) Cool Select Pantry
3-10) Motor Damper
3-11) Water Filter
3-12) Gallon Door Bin
3-13) Vertical Hinged Section
3-14) Evaporator Cover In Refrigerator
3-15) Evaporator In Refrigerator
3-16) Freezer Door
3-17) Pull Out Drawer
3-18) Ice Maker
3-19) Freezer Light
3-20) Door Switch In Freezer
3-21) Evaporator Cover In Freezer
3-22) Evaporator In Freezer
3-23) Machine Compartment
3-24) Electric Box

3-1) Refrigerator Door

Part Name	How To Do	Descriptive Picture
	1. Remove the cap-top table with using a flat-blade(-) screwdriver.	
Refrigerator Door	2. Remove 3 screws of the top- table.	
	3. Remove the 3 housing-connect screws of TOP-TABLE. (Refer to the picture)	
	4. Disengage the housing-connect of upper hinge (left door).	

Part Name	How To Do	Descriptive Picture
	5. Remove the earth-screw of upper hinge.	
Refrigerator Door	 Remove 3 bolt screws of hinge. Caution : Avoid damage or separation of the door when removing the bolt. 	
	7. Remove the door by lifting it straight up.	

3-2) Door Switch In Refrigerator

Part Name	How To Do	Descriptive Picture
Door Switch In Refrigerator	 Remove the magnet switch with using a flat-blade(-) screwdriver. (Refer to the picture) 	M ²

3-3) Door Gasket

Part Name	How To Do	Descriptive Picture
Door Gasket In Refrigerator	1. Remove the door-gasket by pulling it out of the retaining channel.	

3-4) Door Handle

Part Name	How To Do	Descriptive Picture
Door Handle Refrigerator	 Remove the door handle of refrigerator by lifting it up and pulling it out. (Refer to the picture) 	
Door Handle Freezer	 Remove the door handle of freezer by pushing it to the right and pulling it out. (Refer to the picture) 	

3-5) Refrigerator Light

Part Name	How To Do	Descriptive Picture
Refrigerator	 Remove the light cover by pulling it down with pushing the rear of light cover. 	
Light	2. Remove the lamp by turning it counterclockwise.	

3-6) Internal Water Dispenser

Part Name	How To Do	Descriptive Picture
Internal Water Dispenser Cover	1. Remove the internal water dispenser cover by inserting a flat-blade(-) screwdriver to the gap of dispenser with pulling the cover.	Ore touch Water
Water Hose Cap	 Remove the water hose cap by pulling it out. (Refer to the picture) 	

Part Name	How To Do	Descriptive Picture
Micro Switch	 Remove the micro switch with using flat- blade(-) screwdriver. (Refer to the picture) 	
	2. Disengage the Housing Connect. (Refer to the picture)	

3-7) Spill Proof Glass Shelf

Part Name	How To Do	Descriptive Picture
Spill Proof Glass Shelf	1. Remove the shelf by lifting the front plane of the shelf up and pulling it out.	

3-8) Vegetable & Fruit Drawers

Part Name	How To Do	Descriptive Picture
Vegetable & Fruit Drawers	 Remove the vegetable & fruit drawer by pulling the roller part and lifting it up. 	

Part Name	How To Do	Descriptive Picture
Vegetable & Fruit Drawers Shelf	 Remove the vegetable & fruit drawers shelf by pulling it out. (Refer to the picture) 	

3-9) Cool Select Pantry

Part Name	How To Do	Descriptive Picture
Cool Select Pantry	 Remove the cool select pantry by pulling the roller part and lifting it up. 	
Cool Select Pantry Cover	 Remove the cool select pantry cover by lifting the central part of the cover with pushing it to the left. 	
Cool Select Pantry Shelf	 Remove the cool select pantry shelf by lifting the front part of the shelf with pulling it. 	
Cool Select Pantry Rail	 Remove the cool select pantry rail by unscrewing the 3 screw parts and pulling the rail. 	
	 Disconnect the housing connect of internal rail part. (Refer to the picture) 	

3-10) Motor Damper

Part Name	How To Do	Descriptive Picture
Motor Damper	 Remove the cool select pantry. Remove the screw part of lower motor damper part and then push the motor damper down. 	
	 Disengage 2 housing connects of the rear motor damper. (Refer to the picture) 	

3-11) Water Filter (Disassembly)

Part Name	How To Do	Descriptive Picture
Water Filter	 Remove the shelf by lifting the front plane of the shelf up and pulling it out. Remove the water filter by turning it clockwise. (Refer to the picture) 	

3-11) Water Filter (Reassembly)

Part Name	How To Do	Descriptive Picture
Water Filter	 Place the part of (a) arrow (that is indicating in the picture) in the middle of the front filter cover and push it up. 	
	2. Turn the water filter counterclockwise until central horizontal line of filter cover and both ends of water filter label are made all of the same width. (Refer to the picture.)	<image/>

3-12) Gallon Door Bin		
Part Name	How To Do	Descriptive Picture
Gallon Door Bin	 Remove the gallon door bin by lifting it up. (Refer to the picture) 	

3-13) Vertical Hinged Section

Part Name	How To Do	Descriptive Picture
Vertical Hinged Section	 Remove 2 screw cap parts with using flat-blade(-) screwdriver. (Refer to the picture) 	
	2. Unscrew 2 screws.	
	3. Disengage the internal housing connect of vertical hinge.	Par C
	 4. Remove the vertical hinged section by lifting vertical hinge up. (Refer to the picture) 	

3-14) Evaporator Cover In Refrigerator

Part Name	How To Do	Descriptive Picture
	 Remove the angle cap with using a flat-blade screwdriver. (Refer to the picture) 	TWIN COOLING
	2. Unscrew 4 screws.	
Evaporator Cover In Refrigerator	 Remove the the lower part of angle mid by pulling it out and pushing it down. (Refer to the picture) 	
	 4. Remove the hook by pulling it from the lower part and pushing the cover down. (Refer to the picture) 	
	5. Disconnect the housing connect of rear plane. (Refer to the picture)	Project

3-15) Evaporator In Refrigerator

Part Name	How To Do	Descriptive Picture
Evaporator In Refrigerator	 Remove the the housing cover by pushing both lateral sides of the housing cover and pulling it out. (Refer to the picture) 	
	 Disconnect the housing connect part. (Refer to the picture) 	
	3. Unscrew 2 screws.	
	 4. Remove the evaporator by lifting the bottom side of it up and pulling it out. (Refer to the picture) 	

3-16) Freezer Door

Part Name	How To Do	Descriptive Picture
	 Open the freezer door. Remove the tilting pocket by pushing it to the left. (Refer to the picture) 	
	 Remove the 2 support tilting pockets with temporary force. (Refer to the picture) 	
Freezer Door	 Remove the freezer drawer bin by lifting the bottom part of it up. (Refer to the picture) 	
	4. Remove 4 internal bolts at both lateral sides of rail part.(Refer to the picture)	
	5. Remove the freezer door by tilting the bottom part of it and lifting it up.	

3-17) Pull Out Drawer

Part Name	How To Do	Descriptive Picture
Pull Out Drawer	1. Slide the drawer out as much as possible.	
	2. Insert a flat screw driver(-) into the gap and then push it up to diassemble.	
	3. Remove the pull out drawer by lifting the bottom part of drawer bin and pulling it out.	

3-18) Ice Maker

Part Name	How To Do	Descriptive Picture
Ice Maker	1. Remove the ice maker cover by pulling the bottom part of ice maker cover out.	
	2. Unscrew 2 screws.	

Part Name	How To Do	Descriptive Picture
Ice Maker	3. Remove the ice maker by pulling it out.	
	4. Disconnect the housing connector part.	

3-19) Freezer Light

Part Name	How To Do	Descriptive Picture
Freezer Light	 Remove the light by pulling the light cover down with pushing the rear plane of light cover. 	

3-20) Door Switch In Freezer

Part Name	How To Do	Descriptive Picture
Door Switch In Freezer	1. Remove the freezer drawer bin with using flat-blade(-) screwdriver.(Refer to the picture)	AMA.
	2. Disconnect the housing connector part.	

3-21) Evaporator Cover In Freezer

Part Name	How To Do	Descriptive Picture
Evaporator Cover In Freezer	1. Remove the freezer door, freezer drawer bin, pull out drawer, ice maker and then unscrew 2 screws.	
	2. Remove the evaporator cover by pulling the bottom part of it out.	
	3. Disconnect the housing connector part.	

3-22) Evaporator In Freezer

Part Name	How To Do	Descriptive Picture
Evaporator In	 Remove the housing cover by pushing both lateral sides of housing cover part and pulling it out. Remove the housing connector part. 	
Freezer	2. Remove the evaporator by pulling the lower part of evaporator with lifting it up.	

3-23) Machine Compartment

Part Name	How To Do	Descriptive Picture
	1. Unscrew 8 screws of cover comp.	
	2. Disengage the housing connector. (Refer to the picture)	
	3. Remove the hooker of support circuit motor by lifting the hooker up and pulling it out.	
Motor Fan	4. Remove the spring with using flat-blade screwdriver.(Refer to the picture)	F II
	5. Remove the motor fan by pulling the fan out with grasping the motor part.(Refer to the picture)	
	6. Unscrew 2 screws fixed in the motor.	
	7. Remove the hook of motor cover with using a flat-blade (-) screwdriver and then remove the motor.	

Part Name	How To Do	Descriptive Picture
Relay PTC & O/L	1. Disengage the housing connector.	
	 Remove the relay PTC with using a flat-blade screwdriver. (Refer to the picture) 	
	1. Unscrew the water valve fixed in the screw part.	
Water Valve	2. Remove the the hook part of hose fixer by pushing it down.	
	 Remove 2 water hose parts with pushing upper part of ①. (Refer to the picture) 	
	4. Disengage 2 housing connector parts.	
	5. Remove the hose connecting nut with using a wrench(8mm).	

Part Name	How To Do	Descriptive Picture
Power Cord & Noise Filter	1. Unscrew 2 screws.	
	2. Disengage the housing connector.	
	3. Unscrew 3 earth screws.	
	 4. Remove the cover by pushing the hook up with using a flat- blade(-) screwdriver. (Refer to the picture) 	ANA A
	5. Disengage the housing connector to separate the power cord and noise filter.	

3-24) Electric Box

Part Name	How To Do	Descriptive Picture
PBA Main	 Pull the refrigerator forward for having enough space to work at the rear side of the appliance. 	
	2. Unscrew 2 PCB cover fixed screws.	
	3. Disengage all housing connectors connected with main PCB.	
	4. Unscrew 2 PCB fixed screws.	
	5. Remove the main PCB with lifting the upper part of the hook up. (Refer to the picture)	
PBA SMPS	 Remove the cover PCB and then disengage the housing connector connected with main PCB. Remove the SMPS PCB with pushing the lower part of the hook down. 	