

Service Bulletin	
PRODUCT:	Refrigerator
TIP NUMBER:	ASC20060504001
TIP DATE:	05/04/2006
MODELS:	RS253BAWW/XAA,RS255BAWW/XAA, RS253BAWW/XAA, RS253BAVQ/XAA, RS253BABB/XAA, RS253BASB/XAA, RS255BABB/XAA, RS255BASB/XAA, RS257BARS/XAA, RS257BAWW/XAA, RS257BABB/XAA, RS257BARB/XAA, RB195LASW/XAA, RB195LAVQ/XAA, RB195LASH/XAA, RB195ZABB/XAA, RB195ZASW/XAA, RB195DASH/XAA, RB195ZAVQ/XAA, RB195DSBB/XAA, RB195DSB/XAA, RB195DSSB/XAA, RB195DSSB/XAA, RB195DSB/XAA, RB195DSSB/XAA, RB195DSSB/XAA, RB195DSVQ/XAA RB215DSSB/XAA, RB215DSSB/XAA, RB215DSSB/XAA, RB215DSSW/XAA, RB215LABB/XAA, RB215LASH/XAA, RB215LASW/XAA, RB215LABB/XAA, RB215LASH/XAA, RB215LASW/XAA, RB215LABP/XAA, RB215ZASB/XAA, RB215ZASW/XAA, RB215ZASH/XAA, RB215ZASW/XAA, RB215ZASW/XAA, RB215ZASH/XAA, RB215ZASB/XAA, RB215ZASW/XAA, RB215ZASH/XAA, RB215ZASB/XAA, RM255BARB/XAA, RM255LASH/XAA RM255LABP/XAA
Chassis	ATOP, NEXT and W2

SUBJECT: PLC (Power Line Communication) Error in Diagnostic Mode

SYMPTOM: - When Self-Diagnostic mode is selected, the LED segment indicating PLC error may be blinking, see figure 1. PLC error does **NOT** mean the board should be replaced.




Figure 1

Explanation: The PLC error indicates that the unit was not able to connect to a home network system. These models do not have a home network interface so this error is meaningless. If this error is displayed during diagnostic testing please ignore it.

<u>Note:</u> Consult the Samsung Service Website at (<u>service.samsungportal.com)</u> for the Service Manual and other information on this product.

This information is published for experienced repair technicians only and is not intended for use by the public. It does not contain warnings to advise non-technical individuals of possible dangers in attempting to service a product. Only experienced professional technicians should repair products powered by electricity. Any attempt to service or repair the product or products dealt with in this information by anyone else could result in serious injury or death. Information provided in this bulletin is subject to change or update without notice.